



Fitform® Thermoforming Bottom Webs for EO and/or Irradiation

SK DT

Designed with Uncoated Tyvek®





SK DT - Designed with Uncoated Tyvek®

SK DT is flexible thermoforming packaging material for medical device applications where Tyvek® is required. Intended for EO and Irradiation applications.

Technical Details

- Coextruded PE/PA/PE-blend
- 75-250 microns / 3-10 mil

Benefits

- Sealable and peelable with uncoated Tyvek®
- A lower cost package versus films with coated Tyvek®
- Excellent formability and cutting properties for easy packing process.

Applications

- Thermoforming applications where Tyvek® is required
- Premium syringes, catheters and connectors
- For EO and Irradiation sterilization

DuPont™ and Tyvek® are trademarks of DuPont de Nemours, Inc.

For further Information please contact:
medicaldevice@wiicare.com
www.wiicare.com

Wiicare® is a registered trademark of Wihuri Packaging Oy.

 | **WICARE**

Winpak reserves right to make changes at any time without notice.